

DKTV Kundecenter

Vidensbase > Router / Netværksboks > Router > Jensen > Jensen - Ændring af kanal

Jensen - Ændring af kanal

#Marketing - 2018-06-01 - Jensen

For at kunne ændre denne funktion forudsætter det, at du er logget ind i routeren.

[Vejledning kan findes her](#)

Ændring af kanal

1. Log ind i routeren - se ovenstående
2. Vælg fanebladet "Advanced"
3. Tryk på "2.4Ghz wireless", hvis du ønsker at skifte kanal på 2.4Ghz netværket.
Tryk på "5Ghz wireless", hvis du ønsker at skifte kanal på 5Ghz netværket.
4. I feltet "Channel Number" ændre du kanalen til den ønskede kanal.
Hvis kanalen ønskes ændret for 5GHz netværket, kan dette gøres ved at klikke på "5Ghz wireless" i venstre menu og følge samme fremgangsmåde.
5. Tryk på "Apply"

The screenshot shows the Jensen router's web interface. At the top, there's a status bar with 'Jensen OF SCANDINAVIA' logo, internet status (Connected), firmware version (v1.05), and WiFi details (JensenLynx5000, JensenLynx5000_5G). A router icon and 'Modelno: Lynx5000' are on the right. The main area has two tabs: 'BASIC' and 'ADVANCED' (highlighted with a green box). The left sidebar lists various settings, with '2.4GHz Wireless' (highlighted with a green box) selected. Under it, 'Basic Settings' is also highlighted with a green box. The 'Basic Settings' section contains fields for Mode (Access Point), Band (2.4 GHz (B+G+N)), SSID (JensenLynx5000), and Channel Number (6, highlighted with a green box). There's a 'Show Active Clients' button and 'APPLY' (highlighted with a green box) and 'CANCEL' buttons at the bottom right.

Relateret indhold

- [Jensen - Log ind i routeren](#)
- [Jensen - Ændring af funktion \(bridge-/routermode\)](#)
- [Jensen - Ændring af netværksnavn/SSID](#)
- [Jensen - Ændring af netværkskode/Wireless password](#)