

DKTV Kundecenter

Vidensbase > Router / Netværksboks > Router > D-Link > D-Link - Ændring af netværksnavn/kode

D-Link - Ændring af netværksnavn/kode

- 2018-06-01 - D-Link

For at kunne ændre denne funktion forudsætter det, at du er logget ind i routeren.

[Vejledning kan findes her](#)

Ændring af netværksnavn/SSID

1. Log ind i routeren - se ovenstående
2. Vælg "Settings"
3. Tryk på "Wireless"
4. I felterne "Wi-Fi Name (SSID)" angiver du dit ønskede netværksnavn/SSID
5. I felterne "password" angiver du din ønskede adgangskode
6. Tryk på "Save" for at gemme ændringerne.

D-Link
DIR-880L HW:A1 FW:1.05WW

Home | Settings | Features | Management

Wireless

Use this section to configure the wireless settings of your D-Link Router. Please make sure that any changes made in this section will need to be made on your wireless device.

Settings >> Wireless

Wizard
Internet
Wireless
Network
SharePort
mydlink

Guest Zone Save

Smart Connect

Smart Connect: Disabled

2.4GHz

Status: Enabled

Wi-Fi Name (SSID): dktv-dlink

Password: dktvsupport

[Advanced Settings...](#)

5GHz

Status: Enabled

Wi-Fi Name (SSID): dktv-dlink-5G

Password: dktvsupport

[Advanced Settings...](#)

Relateret indhold

- [D-link DIR-842](#)
- [D-link DIR-859](#)
- [D-link DIR-878](#)