

DKTV Kundecenter

Knowledgebase > Router / Netværksboks > Router > D-Link > D-Link - Ændring af funktion (bridge-/routermode)

D-Link - Ændring af funktion (bridge-/routermode)

- 2018-06-01 - D-Link

For at kunne ændre denne funktion forudsætter det, at du er logget ind i routeren.

[Vejledning kan findes her](#)

Ændring af funktion (bridge/router mode)

1. Log ind i routeren - se ovenstående
2. Vælg "Settings"
3. Klik på "Internet"
4. I feltet "Device mode" ændres routerens funktion fra "Router mode" til "Bridge mode" eller omvendt.
5. Klik på "Save"

The screenshot shows the D-Link web interface for a DIR-880L router. The top navigation bar includes 'Home', 'Settings', 'Features', and 'Management'. The 'Settings' tab is active, and the 'Internet' sub-tab is selected. A dropdown menu is open over the 'Internet' tab, showing options: Wizard, Internet (selected), Wireless, Network, SharePort, and mydlink. The main content area is titled 'Internet' and contains instructions on configuring the Internet connection. Below the instructions, there are two dropdown menus: 'Device Mode' set to 'Router Mode' and 'My Internet Connection is' set to 'Dynamic IP (DHCP)'. A 'Save' button is located at the bottom right of the settings area. A link for 'Advanced Settings...' is also visible at the bottom right.

Related Content

- [D-link DIR-842](#)
- [D-link DIR-859](#)
- [D-link DIR-878](#)